

Manual for Programming Alltime AT900A – AT900D

Just Change Time only – on AT900A and AT900D

Open cover, key turns clockwise.
Setup switch just on inside top edge on the right.
Slide black SETUP switch to LEFT.
(Use – or + buttons at left of setup switch to change numbers.)

“01” is flashing,
Press “ + ” button 2 times.
Then “03” is flashing.
Press ENTER 1 time.
(Use – or + buttons at left of setup switch to change numbers.)
For HOURS, then press enter.
(Use – or + buttons at left of setup switch to change numbers.)
For MINUTES, then press enter.
Slide set-up switch to the RIGHT. Close lid.



If clock loses memory after power outages in future:

Unplug from power. Open cover, key turns clockwise. Replace Button battery about the size of 10 cents. From Chemists, Dick smiths, Tandy etc. Around \$5. (CR2032.)
2 TOP SCREWS OUT, EASE COVER OUT UNCLIP BOTTOM AND DO NOT STREACH 2 CABLES. Button battery is top right of main circuit board. Then clock will not loose memory during power outages.
Then program the clock

Start here with normal programing if reset is NOT pressed.

Open cover, key turns clockwise.
Setup switch just on inside top edge on the right.
Slide black SETUP switch to LEFT.
(Use – or + buttons at left of setup switch to change numbers.)

Setup-01 : PRESS ENTER, enter YEAR - - - - Press ENTER.
Setup-02 : PRESS ENTER, enter MONTH - -. Press ENTER. then DATE. - -
Press ENTER.
Setup-03 : PRESS ENTER, enter HOUR. Press ENTER. then MINUTES. Press
ENTER.
Setup-04 : PRESS ENTER, enter 00. Press ENTER. 00. LINE CHANGE TIME.
Press ENTER.
Setup-05 : PRESS ENTER, enter 01. Press ENTER.
Setup-06 : Press ENTER, Weekly enter 01. Press ENTER. Pay finishes (M~S =
01~07) Wednesday Enter 03. ENTER.
(Setup-06 : Fortnightly or Monthly, Press ENTER, enter 00. Press ENTER.)
Setup-07 : PRESS ENTER, HOURS MODE, enter 24. Press ENTER.

Setup-08 : PRESS ENTER, COLUMN-ROW POSITION.

Analogue = enter 8 Press ENTER. enter 15. Press ENTER.

Setup-09 : For daylight saving. PRESS ENTER, DAYLIGHT SAVING TIMES. 10 Press ENTER, 05 Press ENTER. 02 Press ENTER, 04 Press ENTER. 05 Press ENTER. 03. Press ENTER.

(No Daylight saving = Setup-09 : Press “ + ” button one time only.

Setup-10 : PRESS ENTER, PRINTING FORMAT 00=24 hour.
Press ENTER.

Setup-11 : PRESS ENTER, enter 01. (MUST BE 01.) Press ENTER.

Column Shift Setup: Press COLUMN Button once (Third from left.)

Setup-01 for First IN column.

PRESS ENTER. 00 PRESS ENTER, 01 PRESS ENTER. Column 1 = 01
PRESS ENTER, Sunday flashing PRESS ENTER.

Setup-02 for First OUT column.

PRESS ENTER. 10 PRESS ENTER, 15 PRESS ENTER. Column 2 = 02
PRESS ENTER, Sunday flashing PRESS ENTER.

Setup-03 for First IN column.

PRESS ENTER. 10 PRESS ENTER, 50 PRESS ENTER. Column 3 = 03
PRESS ENTER, Sunday flashing PRESS ENTER.

Setup-04 for First OUT column.

PRESS ENTER. 11 PRESS ENTER, 45 PRESS ENTER. Column 4 = 04
PRESS ENTER, Sunday flashing PRESS ENTER

Setup-05 for First IN column.

PRESS ENTER. 13 PRESS ENTER, 45 PRESS ENTER. Column 5 = 05
PRESS ENTER, Sunday flashing PRESS ENTER.

Setup-06 for First OUT column.

PRESS ENTER. 14 PRESS ENTER, 20 PRESS ENTER. Column 6 = 06
PRESS ENTER, Sunday flashing PRESS ENTER

Then slide SETUP switch to the Right. Finished

This is for use after you initially pressed the reset button before programming.

Signal output: PRESS MUSIC button 1 time,

Setup-01 for First Ring.

PRESS ENTER, change to 07 using + or – buttons, then ENTER, change to 00 then ENTER.
Change to 02 for External signal output. Press ENTER.

DURATION, change to 04 seconds, then press ENTER.

Weekdays. Press MUSIC button 5 times to cancel Sunday, Monday, Tuesday, Wednesday,
Thursday. Then press + button 1 time to choose **Friday**, (It will show the days it rings,

blank day = no ring.) (+ button = no change. Music button = change setting.)
then Press MUSIC button 1 time to cancel Saturday. Then PRESS ENTER.

Setup-02 for First Ring.

PRESS ENTER, change to 07 using + or – buttons, then ENTER, change to 30 then ENTER.

Change to 02 for External signal output. Press ENTER.

DURATION, change to 04 seconds, then press ENTER.

Weekdays. Press MUSIC button 1 time to cancel Sunday. Then press + button 4 times to choose **Monday, Tuesday, Wednesday, Thursday**, then Press MUSIC button 2 times to cancel Friday, Saturday. Then PRESS ENTER.

Setup-03 for Second Ring.

PRESS ENTER, change to 10 using + or – buttons, then ENTER, change to 30 then ENTER.

Change to 02 for External signal output. Press ENTER.

DURATION, change to 04 seconds, then press ENTER.

Weekdays. Press MUSIC button 1 time to cancel Sunday. Then press + button 4 times to choose **Monday, Tuesday, Wednesday, Thursday**, then Press MUSIC button 2 times to cancel Friday, Saturday. Then PRESS ENTER.

.

Setup-04 for Third Ring. etc

PRESS ENTER, change to 11 using + or – buttons, then ENTER, change to 00 then ENTER.

Change to 02 for External signal output. Press ENTER.

DURATION, change to 04 seconds, then press ENTER.

Weekdays. Press MUSIC button 1 time to cancel Sunday. Then press + button 4 times to choose **Monday, Tuesday, Wednesday, Thursday**, then Press MUSIC button 2 times to cancel Friday, Saturday. Then PRESS ENTER.

.

Setup-05 for Fourth Ring. etc

PRESS ENTER, change to 11 using + or – buttons, then ENTER, change to 15 then ENTER.

Change to 02 for External signal output. Press ENTER.

DURATION, change to 04 seconds, then press ENTER.

Weekdays. Press MUSIC button 5 times to cancel Sunday, Monday, Tuesday, Wednesday, Thursday. Then press + button 1 time to choose **Friday**, then Press MUSIC button 1 time to cancel Saturday. Then PRESS ENTER.

Setup-06 for Fifth Ring. etc

PRESS ENTER, change to 13 using + or – buttons, then ENTER, change to 30 then ENTER.

Change to 02 for External signal output. Press ENTER.

DURATION, change to 04 seconds, then press ENTER.

Weekdays. Press MUSIC button 1 time to cancel Sunday. Then press + button 4 times to choose **Monday, Tuesday, Wednesday, Thursday**, then Press MUSIC button 2 times to cancel Friday, Saturday. Then PRESS ENTER.

Setup-07 for sixth Ring. etc

PRESS ENTER, change to 14 using + or – buttons, then ENTER, change to 00 then ENTER.

Change to 02 for External signal output. Press ENTER.

DURATION, change to 04 seconds, then press ENTER.

Weekdays. Press MUSIC button 1 time to cancel Sunday. Then press + button 4 times to choose **Monday, Tuesday, Wednesday, Thursday**, then Press MUSIC button 2 times to cancel Friday, Saturday. Then PRESS ENTER.

Setup-08 for seventh Ring. etc

PRESS ENTER, change to 15 using + or – buttons, then ENTER, change to 00 then ENTER.

Change to 02 for External signal output. Press ENTER.

DURATION, change to 04 seconds, then press ENTER.

Weekdays. Press MUSIC button 5 times to cancel Sunday, Monday, Tuesday, Wednesday, Thursday. Then press + button 1 time to choose **Friday**, then Press MUSIC button 1 time to cancel Saturday. Then PRESS ENTER

Setup-09 for seventh Ring. etc

PRESS ENTER, change to 17 using + or – buttons, then ENTER, change to 00 then ENTER.

Change to 02 for External signal output. Press ENTER.

DURATION, change to 04 seconds, then press ENTER.

Weekdays. Press MUSIC button 1 time to cancel Sunday. Then press + button 4 times to choose **Monday, Tuesday, Wednesday, Thursday**, then Press MUSIC button 2 times to cancel Friday, Saturday. Then PRESS ENTER

Then slide SETUP switch to the Right. Finished

Email us for any other instructions at: john@alltime.com.au

Free call if having problems, on: **1800 220 110** Compliments of Alltime™

(c) Copyright 2014 { Western Sunset Pty Ltd } All Rights Reserved. Alltime is a trade mark owned by Western Sunset Pty Ltd.