


Table of Contents

1.0. Reset.....	1
2.0. Date/Time Settings.....	1
3.0. Daylight Saving Settings.....	2
4.0. Program Settings (For Unset Digital Timer).....	3
Mon-Fri: 7:27.....	3
Mon-Fri: 7:30.....	4
Mon-Fri: 10:00.....	6
Mon-Fri: 10:12.....	7
Mon-Fri: 10:15.....	9
Mon-Thu: 13:00.....	10
Mon-Fri: 13:27.....	12
Mon-Fri: 13:30.....	13
Mon-Thu: 15:57.....	15
Mon-Thu: 16:00.....	16
5.0. Taking Out 07:00 and 15:30, And Adding 13:30.....	18
Delete 07:00.....	18
Delete 15:30.....	18
Add 13:30.....	19
























No Daylight Saving:

1. In the main screen, **press OK** → “Prog” flashing
2. **Press Δ twice** until see ⚙ * flashing
3. **Press OK** → “Auto” flashing
4. **Press Δ twice** → “Off” flashing
5. **Press OK** to go to the main menu
6. Done → Close the cover































1.0. Reset

Although the clock of the device is already programmed, if a RESET is needed (blank display, inconsistent data, etc.), press at the same time the four keys of  during 3 seconds. In this moment, the device loses all data and goes to clock setting mode, directly to program year, month, day, day of the week, hour and minutes.


2.0. Date/Time Settings

- 2.1. In the main screen, press  → Prog flashing
- 2.2. Press  once →  flashing
- 2.3. Press  → year number flashing
- 2.4. Press  or  until see desired year of “2012”
- 2.5. Press  → month number flashing
- 2.6. Press  or  until see desired month of “11”
- 2.7. Press  → day number flashing
- 2.8. Press  or  until see desired day of “27”
- 2.9.   Press  → 7 flashing (Monday is 1 - Sunday is 7)
- 2.10. Press  until see desired day number flashing → in this case, 27/11/2012 is Tuesday so that 2 is correct
- 2.11. Press  → hour number flashing
- 2.12. Press  or  until see desired hour
- 2.13. Press  → minute number flashing
- 2.14. Press  or  until see desired minute
- 2.15. Press  to go to the main screen

3.0. Daylight Saving Settings

- 3.1. In the main screen, press  → Prog flashing
- 3.2. Press  twice until see  flashing
- 3.3. Press  → “Auto” flashing
- 3.4. Press  once → “Pro” flashing
- 3.5. Press  → month number flashing
- 3.6. Press  or  until see desired month of “10”
- 3.7. Press  → day number flashing
- 3.8. Press  or  until see desired day of “07”
- 3.9. Press  → hour number flashing
- 3.10. Press  or  until see desired hour of “02”
- 3.11. Press  → minute number flashing
- 3.12. Press  or  until see desired minute of “00”
- 3.13. Press  → month number flashing
- 3.14. Press  or  until see desired month of “04”
- 3.15. Press  → day number flashing
- 3.16. Press  or  until see desired day of “07”
- 3.17. Press  → hour number flashing
- 3.18. Press  or  until see desired hour of “03”
- 3.19. Press  → minute number flashing
- 3.20. Press  or  until see desired minute of “00”
- 3.21. Press  to go to the main screen



4.0. Program Settings (For Unset Digital Timer)

4.1. In the main screen, press  → Prog flashing


4.2. Press  →  - - : - - comes up

Mon-Fri: 7:27


4.3. Press  →  flashing

4.4. Press  twice until see  flashing (⌚ means pulse)


4.5. Press  →  hour number flashing


4.6. Press  until see desired hour of "07"

4.7. Press  →  minute number flashing













4.8. Press  until see desired minute of "27"

4.9. Press  →  pulse number flashing








4.10. Press  until see desired pulse of "03"

4.11. Press  →  flashing (Monday is 1 - Sunday is 7)


4.12. Press  to accept Monday →  flashing



- 4.13. Press  to accept Tuesday →  flashing
- 4.14. Press  to accept Wednesday →  flashing
- 4.15. Press  to accept Thursday →  flashing
- 4.16. Press  to accept Friday →  flashing
- 4.17. Press  once to skip Saturday →  flashing
- 4.18. Press  once to skip Sunday →  comes up


Mon-Fri: 7:30



- 4.19. Press  →  flashing
- 4.20. Press  twice until see  flashing (⌚ means pulse)
- 4.21. Press  →  hour number flashing
- 4.22. Press  until see desired hour of "07"

4.23. Press  →  minute number flashing



4.24. Press  until see desired minute of "30"



4.25. Press  →  pulse number flashing



4.26. Press  until see desired pulse of "03"

4.27. Press  →  flashing (Monday is 1 - Sunday is 7)

4.28. Press  to accept Monday →  flashing

4.29. Press  to accept Tuesday →  flashing

4.30. Press  to accept Wednesday →  flashing


4.31. Press  to accept Thursday →  flashing



4.32. Press  to accept Friday →  flashing

4.33. Press  once to skip Saturday →  flashing


4.34. Press  once to skip Sunday →  comes up

Mon-Fri: 10:00


4.35. Press  →  flashing

4.36. Press  twice until see  flashing (⌚ means pulse)


4.37. Press  →  hour number flashing



4.38. Press  until see desired hour of "10"

4.39. Press  →  minute number flashing













4.40. Press  until see desired minute of "00"

4.41. Press  →  pulse number flashing








4.42. Press  until see desired pulse of "03"

4.43. Press  →  flashing (Monday is 1 - Sunday is 7)


4.44. Press  to accept Monday →  flashing



- 4.45. Press  to accept Tuesday →  flashing
- 4.46. Press  to accept Wednesday →  flashing
- 4.47. Press  to accept Thursday →  flashing
- 4.48. Press  to accept Friday →  flashing
- 4.49. Press  once to skip Saturday →  flashing
- 4.50. Press  once to skip Sunday →  comes up


Mon-Fri: 10.12



- 4.51. Press  →  flashing
- 4.52. Press  twice until see  flashing (⌋ means pulse)
- 4.53. Press  →  hour number flashing
- 4.54. Press  until see desired hour of "10"

4.55. Press  →  minute number flashing

4.56. Press  until see desired minute of "12"



4.57. Press  →  pulse number flashing



4.58. Press  until see desired pulse of "03"

4.59. Press  →  flashing (Monday is 1 - Sunday is 7)





4.60. Press  to accept Monday →  flashing

4.61. Press  to accept Tuesday →  flashing


















4.62. Press  to accept Wednesday →  flashing













4.63. Press  to accept Thursday →  flashing

4.64. Press  to accept Friday →  flashing








- 4.65. Press  once to skip Saturday →  flashing
- 4.66. Press  once to skip Sunday →  comes up



















Mon-Fri: 10:15





- 4.67. Press  →  flashing
- 4.68. Press  twice until see  flashing (⌚ means pulse)
- 4.69. Press  →  hour number flashing
- 4.70. Press  until see desired hour of "10"
- 4.71. Press  →  minute number flashing
- 4.72. Press  until see desired minute of "15"
- 4.73. Press  →  pulse number flashing
- 4.74. Press  until see desired pulse of "03"
- 4.75. Press  →  flashing (Monday is 1 - Sunday is 7)
- 4.76. Press  to accept Monday →  flashing

- 4.77. Press  to accept Tuesday →  flashing
- 4.78. Press  to accept Wednesday →  flashing
- 4.79. Press  to accept Thursday →  flashing
- 4.80. Press  to accept Friday →  flashing
- 4.81. Press  once to skip Saturday →  flashing
- 4.82. Press  once to skip Sunday →  comes up


















Mon-Thu: 13:00













- 4.83. Press  →  flashing
- 4.84. Press  twice until see  flashing (⌋ means pulse)
- 4.85. Press  →  hour number flashing
- 4.86. Press  until see desired hour of "13"

- 4.87. Press  →  minute number flashing
- 4.88. Press  until see desired minute of "00"
- 4.89. Press  →  pulse number flashing
- 4.90. Press  until see desired pulse of "03"
- 4.91. Press  →  flashing (Monday is 1 - Sunday is 7)
- 4.92. Press  to accept Monday →  flashing
- 4.93. Press  to accept Tuesday →  flashing
- 4.94. Press  to accept Wednesday →  flashing
- 4.95. Press  to accept Thursday →  flashing
- 4.96. Press  once to skip Friday →  flashing








- 4.97. Press  once to skip Saturday →  flashing
- 4.98. Press  once to skip Sunday →  comes up

Mon-Fri: 13:27


- 4.99. Press  →  flashing
- 4.100. Press  twice until see  flashing (⌚ means pulse)
- 4.101. Press  →  hour number flashing
- 4.102. Press  until see desired hour of "13"
- 4.103. Press  →  minute number flashing
- 4.104. Press  until see desired minute of "27"
- 4.105. Press  →  pulse number flashing
- 4.106. Press  until see desired pulse of "03"
- 4.107. Press  →  flashing (Monday is 1 - Sunday is 7)
- 4.108. Press  to accept Monday →  flashing


- 4.109. Press  to accept Tuesday →  flashing
- 4.110. Press  to accept Wednesday →  flashing
- 4.111. Press  to accept Thursday →  flashing
- 4.112. Press  to accept Friday →  flashing
- 4.113. Press  once to skip Saturday →  flashing
- 4.114. Press  once to skip Sunday →  comes up


Mon-Fri: 13:30



- 4.115. Press  →  flashing
- 4.116. Press  twice until see  flashing (⌋ means pulse)
- 4.117. Press  →  hour number flashing
- 4.118. Press  until see desired hour of "13"

4.119. Press  →  minute number flashing


4.120. Press  until see desired minute of "30"



4.121. Press  →  pulse number flashing



4.122. Press  until see desired pulse of "03"

4.123. Press  →  flashing (Monday is 1 - Sunday is 7)

4.124. Press  to accept Monday →  flashing

4.125. Press  to accept Tuesday →  flashing

4.126. Press  to accept Wednesday →  flashing

4.127. Press  to accept Thursday →  flashing



4.128. Press  to accept Friday →  flashing

4.129. Press  once to skip Saturday →  flashing


4.130. Press  once to skip Sunday → - - : - - comes up

Mon-Thu: 15:57


4.131. Press  →  flashing


4.132. Press  twice until see  flashing (⌚ means pulse)


4.133. Press  →  hour number flashing



4.134. Press  until see desired hour of "15"



4.135. Press  →  minute number flashing













4.136. Press  until see desired minute of "57"

4.137. Press  →  pulse number flashing








4.138. Press  until see desired pulse of "03"

4.139. Press  →  flashing (Monday is 1 - Sunday is 7)


4.140. Press  to accept Monday →  flashing


- 4.141. Press  to accept Tuesday →  flashing
- 4.142. Press  to accept Wednesday →  flashing
- 4.143. Press  to accept Thursday →  flashing
- 4.144. Press  once to skip Friday →  flashing
- 4.145. Press  once to skip Saturday →  flashing
- 4.146. Press  once to skip Sunday →  comes up


Mon-Thu: 16:00



- 4.147. Press  →  flashing
- 4.148. Press  twice until see  flashing (⌋ means pulse)
- 4.149. Press  →  hour number flashing
- 4.150. Press  until see desired hour of "16"

4.151. Press  →  minute number flashing



4.152. Press  until see desired minute of "00"



4.153. Press  →  pulse number flashing



4.154. Press  until see desired pulse of "03"



4.155. Press  →  flashing (Monday is 1 - Sunday is 7)

4.156. Press  to accept Monday →  flashing

4.157. Press  to accept Tuesday →  flashing

4.158. Press  to accept Wednesday →  flashing


4.159. Press  to accept Thursday →  flashing

4.160. Press  once to skip Friday →  flashing


Press  once to skip Saturday → flashing


1 4
2 4
3 4
4 4
5
6
7 4

4.161. Press  once to skip Sunday → Prog - - : - - comes up



4.162. Press  to go to the main screen

5.0. Taking Out 07:00 and 15:30, And Adding 13:30

5.1. In the main screen, press  → Prog flashing



5.2. Press  → Prog **07:00** 03s comes up

Delete 07:00





















5.3. Keep pressing  down and then press 
 → Prog **09:30** 03s comes up











Delete 15:30

5.4. Press  until see Prog **15:30** 03s

5.5. Keep pressing  down and then press 
 → Prog - - : - - comes up

Add 13:30

- 5.6. Press  → C1:OFF flashing
- 5.7. Press  twice until see C1:0n  flashing (⌚ means pulse)
- 5.8. Press  → 00:00  flashing
- 5.9. Press  until see desired hour of "13"
- 5.10. Press  → 00:00  flashing
- 5.11. Press  until see desired minute of "30"
- 5.12. Press  → 00:00  flashing
- 5.13. Press  until see desired pulse of "03"
- 5.14. Press  →  flashing (Monday is 1 - Sunday is 7)
- 5.15. Press  to accept Monday →  flashing
- 5.16. Press  to accept Tuesday →  flashing
- 5.17. Press  to accept Wednesday →  flashing

- 5.18. Press  to accept Thursday →  flashing
- 5.19. Press  to accept Friday →  flashing
- 5.20. Press   to skip Saturday →  flashing
- 5.21. Press   to skip Sunday → - - : - - comes up
- 5.22. Press  to go to the main screen

1 4
2 4
3 4
4 4
5 4
6
7

1 4
2 4
3 4
4 4
5 4
6 4
7

1 4
2 4
3 4
4 4
5 4
6
7.4

Prog